



Installing HID Kit ***By LXEDITION***

Tools:

10mm Socket wrench
Phillips Screwdriver
Cordless Drill with 23mm bit & Phillips bit.
Pair of Scissors

Duration:

50 to 60 minutes

The before picture:



1. Open your hood (bonnet) and with your 10mm socket remove the headlight assembly on both sides. Unplug the wiring harnesses.

2. Now remove the plastic covers for your low beam (dipped) lights as shown below:



3. Next take your drill with 23mm bit and drill out the center of the caps. Should look similar to this.



4. Now remove your existing low beam (dipped) light bulb. Then insert the Xenon Bulb and apply the retaining clip plug the red wire into the yellow and the black into the black as shown below:



5. now fit the wires through the hole you cut out in the cap and fit the rubber boot around the hole and seal it with clear silicone.



6. Next take your ballast plates (Black plastic plate) and fit them inside the hood (bonnet) I uses 3M double sided tape for both but the left side I also screw the plate down. For the right side I installed the ballast using the provided double sided tape and used two plastic tie straps (which are also included) and secured it.



Left Side



Right side.

7. Now take the headlight assembly and fit it back in the Sorento hooking up all the harnesses, the HID kit comes with fool proof connectors so there is only one way to plug them in. But your not done yet.
8. Next you need to replace the fuse with the one provided in the kit. Open up the fuse box, using the tweezers provided in the fuse box area. Pull out the shown below:



The tweezers is that white square you see just right of the arrow.

9. Now your done you can use the smaller plastic ties to clean up the wires but other than that close the hood (bonnet) and turn on the Sorento and enjoy your night driving. Depending on the color rating they should look something like this:

